

HEADWALL CL
EL.=103.03

MATCH (E)
ROMTEC UTILITIES
EQUIPMENT
5-4-20

BERM
LOCATE THE LIFT STATION IN THE
OF THE POND, NOT IN THE POND.
RUN THE GRAVITY PIPE FROM THE
LOW POINT OF THE POND TO THE LIFT
STATION.

